

Menu Item (click link for Sony Help Guide)	Tab	Page
<a href="#">AEL w/ shutter (still image)</a>	Camera 1	10
<a href="#">AF Area Auto Clear</a>	Camera 1	7
<a href="#">AF Area Regist</a>	Camera 1	7
<a href="#">AF drive speed (movie)</a>	Camera 2	2
<a href="#">AF Illuminator (still image)</a>	Camera 1	6
<a href="#">AF in Focus Mag. (still image)</a>	Camera 1	13
<a href="#">AF Micro Adj.</a>	Camera 1	8
<a href="#">AF System (still image)</a>	Camera 1	6
<a href="#">AF Track Sens (movie)</a>	Camera 2	2
<a href="#">AF Track Sens (still image)</a>	Camera 1	6
<a href="#">AF w/ shutter (still image)</a>	Camera 1	6
<a href="#">Airplane Mode</a>	Network	1
<a href="#">Anti-flicker Shoot. (still image)</a>	Camera 1	14
<a href="#">Aperture Drive in AF</a>	Camera 1	8
<a href="#">APS-C/Super 35mm</a>	Camera 1	1
<a href="#">APS-C/Super 35mm</a>	Camera 1	1
<a href="#">Area Setting</a>	Setup	5
<a href="#">Aspect Ratio (still image)</a>	Camera 1	1
<a href="#">Audio Level Display</a>	Camera 2	2
<a href="#">Audio Out Timing</a>	Camera 2	3
<a href="#">Audio Rec Level</a>	Camera 2	2
<a href="#">Audio Recording</a>	Camera 2	2
<a href="#">Audio signals</a>	Camera 2	9
<a href="#">Auto Pwr OFF Temp.</a>	Setup	2
<a href="#">Auto Review</a>	Camera 2	7
<a href="#">Auto Slow Shut. (movie)</a>	Camera 2	2
<a href="#">Av/Tv Rotate</a>	Camera 2	8
<a href="#">Bluetooth Rmt Ctrl</a>	Network	3
<a href="#">Bluetooth Settings</a>	Network	2
<a href="#">Bracket Settings</a>	Camera 1	3
<a href="#">Bracket Settings</a>	Camera 1	3
<a href="#">Center Lock-on AF</a>	Camera 1	6
<a href="#">Cleaning Mode</a>	Setup	2
<a href="#">Clear Image Zoom/Digital Zoom (Zoom)</a>	Camera 2	5
<a href="#">Color Space (still image)</a>	Camera 1	2
<a href="#">Cont. PB for Intvl.</a>	Playback	4
<a href="#">Copying images from one memory card to another (Copy)</a>	Playback	2
<a href="#">Copyright Info</a>	Setup	5
<a href="#">Creative Style</a>	Camera 1	12
<a href="#">Creative Style</a>	Camera 1	12
<a href="#">Creative Style</a>	Camera 1	12
<a href="#">Ctrl w/ Smartphone</a>	Network	1
<a href="#">Custom Key Movie Page 1</a>	Camera 2	8
<a href="#">Custom Key Movie Page 2</a>	Camera 2	8

<a href="#">Custom Key Movie Page 3</a>	Camera 2	8
<a href="#">Custom Key Playback Page 1</a>	Camera 2	8
<a href="#">Custom Key Still Page 1</a>	Camera 2	8
<a href="#">Custom Key Still Page 2</a>	Camera 2	8
<a href="#">Custom Key Still Page 3</a>	Camera 2	8
<a href="#">Date/Time Setup</a>	Setup	5
<a href="#">Del. Reg. AF Area</a>	Camera 1	7
<a href="#">Delete confirm.</a>	Setup	1
<a href="#">Deleting multiple selected images (Delete)</a>	Playback	1
<a href="#">Demo Mode</a>	Setup	3
<a href="#">Dial Ev Comp</a>	Camera 2	9
<a href="#">Dial Setup</a>	Camera 2	8
<a href="#">DISP Button (Monitor/Finder)</a>	Camera 2	6
<a href="#">Disp Cont Shoot Grp</a>	Playback	3
<a href="#">Disp. cont. AF area</a>	Camera 1	7
<a href="#">Display Media Info.</a>	Setup	6
<a href="#">Display Quality</a>	Setup	2
<a href="#">Displaying continuous shooting remaining time indicator (Cont. Shoot. Length)</a>	Camera 2	7
<a href="#">Drive Mode</a>	Camera 1	3
<a href="#">DRO / Auto/HDR</a>	Camera 1	12
<a href="#">DRO / Auto/HDR</a>	Camera 1	12
<a href="#">e-Front Curtain Shut.</a>	Camera 2	4
<a href="#">Edit Device Name</a>	Network	2
<a href="#">Enlarge Init. Mag.</a>	Playback	2
<a href="#">Enlarge Initial Pos.</a>	Playback	2
<a href="#">Enlarging an image being played back (Enlarge Image)</a>	Playback	2
<a href="#">Exp.comp.set</a>	Camera 1	11
<a href="#">Exposure Comp.</a>	Camera 1	9
<a href="#">Exposure Set. Guide</a>	Camera 2	6
<a href="#">Exposure Std. Adjust</a>	Camera 1	10
<a href="#">Exposure step</a>	Camera 1	10
<a href="#">Eye-Start AF (still image)</a>	Camera 1	7
<a href="#">Face Prty in Mlti Mtr</a>	Camera 1	9
<a href="#">Face Registration</a>	Camera 1	14
<a href="#">File Format (movie)</a>	Camera 2	1
<a href="#">File Format (still image)</a>	Camera 1	1
<a href="#">File Number</a>	Setup	5
<a href="#">Finder Color Temp.</a>	Setup	1
<a href="#">Finder Frame Rate (still image)</a>	Camera 2	6
<a href="#">FINDER/MONITOR</a>	Camera 2	6
<a href="#">Flash Comp.</a>	Camera 1	11
<a href="#">Flash Mode</a>	Camera 1	11
<a href="#">Focus Area</a>	Camera 1	5

<a href="#">Focus Magnif. Time</a>	Camera 1	13
<a href="#">Focus Magnifier</a>	Camera 1	13
<a href="#">Focus Mode</a>	Camera 1	5
<a href="#">Focus Settings</a>	Camera 1	5
<a href="#">Folder Name</a>	Setup	6
<a href="#">Format</a>	Setup	5
<a href="#">FTP Transfer Func.</a>	Network	1
<a href="#">Function Menu Set.- Lower</a>	Camera 2	8
<a href="#">Function Ring(Lens)</a>	Camera 2	9
<a href="#">Gamma Disp. Assist</a>	Setup	1
<a href="#">Grid Line</a>	Camera 2	6
HDMI Settings	Setup	3
HDMI Settings	Setup	3
HDMI Settings	Setup	3
HDMI Settings	Setup	3
HDMI Settings	Setup	3
HDMI Settings	Setup	3
<a href="#">High ISO NR (still image)</a>	Camera 1	2
<a href="#">Importing root certification to the camera</a>	Network	2
<a href="#">Initial Focus Mag. (still image)</a>	Camera 1	13
<a href="#">ISO</a>	Camera 1	9
<a href="#">ISO AUTO Min. SS</a>	Camera 1	9
<a href="#">JPEG Image Size (still image)</a>	Camera 1	1
<a href="#">JPEG Quality (still image)</a>	Camera 1	1
<a href="#">Language</a>	Setup	4
<a href="#">Lens Comp.</a>	Camera 1	2
<a href="#">Lens Comp.</a>	Camera 1	2
<a href="#">Lens Comp.</a>	Camera 1	2
<a href="#">Live View Display</a>	Camera 2	7
<a href="#">Loc. Info. Link Set.</a>	Network	2
<a href="#">Lock Operation Parts</a>	Camera 2	9
<a href="#">Long Exposure NR (still image)</a>	Camera 1	2
<a href="#">Marker Display (movie)</a>	Camera 2	3
<a href="#">Marker Settings (movie)</a>	Camera 2	3
<a href="#">Marker Settings (movie)</a>	Camera 2	3
<a href="#">Marker Settings (movie)</a>	Camera 2	3
<a href="#">Marker Settings (movie)</a>	Camera 2	3
<a href="#">Memory (Camera Settings 1 &amp; 2)</a>	Camera 1	3
<a href="#">Metering Mode</a>	Camera 1	9
<a href="#">MF Assist (still image)</a>	Camera 1	13
<a href="#">Monitor Brightness</a>	Setup	1
<a href="#">MOVIE Button</a>	Camera 2	9
<a href="#">Movie w/ shutter</a>	Camera 2	3
<a href="#">Movie: Exposure Mode</a>	Camera 2	1

<a href="#">New Folder</a>	Setup	6
<a href="#">NTSC/PAL Selector</a>	Setup	2
<a href="#">PB Speed for Intvl</a>	Playback	4
PC Remote Settings	Setup	4
PC Remote Settings	Setup	4
<a href="#">Peaking Setting</a>	Camera 1	13
<a href="#">Peaking Setting</a>	Camera 1	13
<a href="#">Peaking Setting</a>	Camera 1	13
<a href="#">Phase Detect. Area</a>	Camera 1	8
<a href="#">Photo Capture</a>	Playback	2
<a href="#">Picture Effect</a>	Camera 1	12
<a href="#">Picture Profile</a>	Camera 1	12
<a href="#">Playing back images on the image index screen (Image Index)</a>	Playback	3
<a href="#">Playing back images using slideshow (Slide Show)</a>	Playback	2
<a href="#">Pre-AF (still image)</a>	Camera 1	7
<a href="#">Priority Set in AF-C</a>	Camera 1	5
<a href="#">Priority Set in AF-S</a>	Camera 1	5
<a href="#">Priority Set in AWB</a>	Camera 1	12
<a href="#">Protecting images (Protect)</a>	Playback	1
<a href="#">Proxy Recording</a>	Camera 2	1
<a href="#">Pwr Save Start Time</a>	Setup	2
<a href="#">Px. Shift Multi Shoot</a>	Camera 1	3
<a href="#">Px. Shift Multi Shoot</a>	Camera 1	3
<a href="#">Rating</a>	Playback	1
<a href="#">Rating Set(Cust Key)</a>	Playback	1
<a href="#">RAW File Type (still image)</a>	Camera 1	1
Rec. Media Settings	Setup	6
Rec. Media Settings	Setup	6
Rec. Media Settings	Setup	6
<a href="#">Recall (Camera Settings 1 &amp; 2)</a>	Camera 1	3
<a href="#">Record Setting (movie)</a>	Camera 2	1
<a href="#">Recover Image DB</a>	Setup	6
<a href="#">Red Eye Reduction</a>	Camera 1	11
<a href="#">Regist. Faces Priority</a>	Camera 1	14
<a href="#">Registering shooting settings to a custom key (Reg Cust Shoot Set)</a>	Camera 1	4
<a href="#">Release w/o Card</a>	Camera 2	4
<a href="#">Release w/o Lens</a>	Camera 2	4
<a href="#">Remote Ctrl</a>	Setup	3
<a href="#">Reset EV Comp.</a>	Camera 1	9
<a href="#">Reset Network Set.</a>	Network	2
<a href="#">Rotating an image (Rotate)</a>	Playback	1
<a href="#">Rotating recorded images automatically (Display Rotation)</a>	Playback	3

<a href="#">S&amp;Q Motion: Exposure Mode</a>	Camera 2	1
<a href="#">S&amp;Q Settings</a>	Camera 2	1
<a href="#">S&amp;Q Settings</a>	Camera 2	1
<a href="#">Select Media (Memory recall)</a>	Camera 1	3
<a href="#">Select REC Folder</a>	Setup	6
<a href="#">Selecting which memory card to play back (Select PB Media)</a>	Playback	3
<a href="#">Send to Computer</a>	Network	1
<a href="#">Send to Smartphone</a>	Network	1
<a href="#">Send to Smartphone</a>	Network	1
<a href="#">Set File Name</a>	Setup	5
<a href="#">Set. Face Prty in AF</a>	Camera 1	6
<a href="#">Set. Face Prty in AF</a>	Camera 1	6
<a href="#">Setting Reset</a>	Setup	7
<a href="#">Setting the method for jumping between images (Image Jump Setting)</a>	Playback	3
<a href="#">Silent Shooting (still image)</a>	Camera 2	4
<a href="#">Specifying images to be printed (Specify Printing)</a>	Playback	1
<a href="#">Spot Metering Point</a>	Camera 1	10
<a href="#">SteadyShot</a>	Camera 2	4
<a href="#">SteadyShot Settings</a>	Camera 2	4
<a href="#">SteadyShot Settings</a>	Camera 2	4
<a href="#">Switching between still images and movies (View Mode)</a>	Playback	3
<a href="#">Swt. V/H AF Area</a>	Camera 1	5
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">TC/UB Settings</a>	Setup	3
<a href="#">Touch Operation</a>	Setup	2
<a href="#">Touch Pad Settings</a>	Setup	3
<a href="#">Touch Pad Settings</a>	Setup	3
<a href="#">Touch Pad Settings</a>	Setup	3
<a href="#">Touch Panel/Pad</a>	Setup	3
<a href="#">USB Connection</a>	Setup	4
<a href="#">USB LUN Setting</a>	Setup	4
<a href="#">USB Power Supply</a>	Setup	4
<a href="#">Version</a>	Setup	7
<a href="#">Video Light Mode</a>	Camera 2	3
<a href="#">View on TV</a>	Network	1
<a href="#">Viewfinder Bright.</a>	Setup	1
<a href="#">Volume Settings</a>	Setup	1
<a href="#">White Balance</a>	Camera 1	12

<a href="#">WPS Push</a>	Network	2
<a href="#">Access Point Set.</a>	Network	2
<a href="#">Disp MAC Address</a>	Network	2
<a href="#">SSID/PW Reset</a>	Network	2
<a href="#">Wind Noise Reduct.</a>	Camera 2	3
<a href="#">Wireless Flash</a>	Camera 1	11
<a href="#">Zebra Setting</a>	Camera 2	6
<a href="#">Zebra Setting</a>	Camera 2	6
<a href="#">Zoom Ring Rotate</a>	Camera 2	5
<a href="#">Zoom Setting</a>	Camera 2	5
<a href="#">4K Output Sel. (movie)</a>	Setup	4

Category	Sub Menu Item	Comments/Defaults
Exposure2		
AF3		
AF3		
Movie 2	On	
AF2		
Focus Assist		
AF4		
AF2		
Movie 2		
AF2		
AF2		
Network 1		
Shooting Assist		
AF4		
Quality / Image Size1	APS-C S35 Shooting	
Quality / Image Size1	APS-C S35 Shooting:Manual	
Setup 5	[set as desired]	
Quality / Image Size1		
Movie 2	Off	
Movie 3	SingleShooting	
Movie 2	Off	
Movie 2	Off	
Custom Operation 2		
Setup 2	Std.	
Display/Auto Review 2	On	
Movie 2		
Custom Operation 1		
Network 3		
Network 2		
Shoot Mode/Drive1	Selftimer during Bracketing	
Shoot Mode/Drive1	Bracket Order	
AF2		
Setup 2	[set as desired]	
Zoom		
Quality / Image Size2		
Playback 4		
Playback 2		
Setup 5	[set as desired]	
Color/WB/Img Processing	Contrast	
Color/WB/Img Processing	Saturation	
Color/WB/Img Processing	Sharpness	
Network 1		
Custom Operation 1	Auto	<a href="#">Control Wheel</a>
Custom Operation 1	Off	Multi-Slc Center Button

Custom Operation 1	Auto	AEL Button
Custom Operation 1	[set as desired]	Custom Button 1
Custom Operation 1	Off	<a href="#">Control Wheel</a>
Custom Operation 1	ISO Auto	Multi-Slc Center Button
Custom Operation 1	On	AEL Button
Setup 5	[set as desired]	
AF3		
Setup 1	Cancel first	
Playback 1		
Setup 3		
Custom Operation 2		
Custom Operation 1		
Display/Auto Review 1	Off	
Playback 3		
AF3		
Setup 6	[set as desired]	
Setup 2	Std.	
Display/Auto Review 2	Off	
Shoot Mode/Drive1	<a href="#">Drive Mode opt</a>	
Color/WB/Img Processing	<a href="#">D-Range Opt. (DRO)</a>	
Color/WB/Img Processing	<a href="#">Auto HDR</a>	
Shutter/Steady Shot		
Network 2		
Playback 2		
Playback 2		
Playback 2		
FLASH		
Exposure1		
Display/Auto Review 1		
Exposure2		
Exposure2		
AF3		
Exposure1		
Shooting Assist		
Movie 1		
Quality / Image Size1		
Setup 5	[set as desired]	
Setup 1	[set as desired]	
Display/Auto Review 1		
Display/Auto Review 1	3 Std	
FLASH		
FLASH		
AF1	Focus Area Options	



Focus Assist		
Focus Assist		
AF1		
AF1		
Setup 6	[set as desired]	
Setup 5	[set as desired]	
Network 1		
Custom Operation 1	<a href="#">Function Lower 1</a>	
Custom Operation 2		
Setup 1	Off	
Display/Auto Review 1	Off	
Setup 3	<a href="#">HDMI Resolution</a>	
Setup 3	<a href="#">24p/60p Output (movie) (Only for 1080 60i compatibl</a>	
Setup 3	<a href="#">HDMI Info. Display</a>	
Setup 3	<a href="#">TC Output (movie)</a>	
Setup 3	<a href="#">REC Control (movie)</a>	
Setup 3	<a href="#">CTRL FOR HDMI</a>	
Quality / Image Size2		
Network 2		
Focus Assist		
Exposure1	ISO options	
Exposure1	ISO Auto Opt.	
Quality / Image Size1		
Quality / Image Size1		
Setup 4	English	
Quality / Image Size2	<a href="#">Lens Comp. -Shading</a>	
Quality / Image Size2	<a href="#">Lens Comp. CA</a>	
Quality / Image Size2	<a href="#">Lens Comp. Dist</a>	
Display/Auto Review 2	[set as desired]	
Network 2		GPS
Custom Operation 2		
Quality / Image Size2		
Movie 3	Off	
Movie 3	0 → - → +	Center
Movie 3	OFF	Aspect
Movie 3		Safety Zone
Movie 3	[set as desired]	Guideframe
Shoot Mode/Drive1		Save Settings to Dial C1,2,3 or Card
Exposure1	Metering Mode Spot Option	
Focus Assist		
Setup 1	[set as desired]	
Custom Operation 2		
Movie 3	Slot 1	
Movie 1	RAW & JPEG	

Setup 6	[set as desired]	
Setup 2	[set as desired]	
Playback 4		
Setup 4		<a href="#">Still Img. Save Dest.</a>
Setup 4		<a href="#">RAW+J PC Save Img</a>
Focus Assist	Peaking Display	
Focus Assist	Peaking Level	
Focus Assist	Peaking Color	
AF4		
Playback 2		
Color/WB/Img Processing	[set as desired]	
Color/WB/Img Processing	Options	
Playback 3		
Playback 2		
AF3		
AF1		
AF1		
Color/WB/Img Processing		
Playback 1		
Movie 1	Off	
Setup 2	1min	
Shoot Mode/Drive1		
Shoot Mode/Drive1	Pixel Shift Options	
Playback 1		
Playback 1		
Quality / Image Size1		
Setup 6	Slot 1	<a href="#">Prioritize Rec. Media</a>
Setup 6		<a href="#">Recording Mode</a>
Setup 6		<a href="#">Auto Switch Media</a>
Shoot Mode/Drive1		
Movie 1		
Setup 6	[set as desired]	
FLASH		
Shooting Assist		
Shoot Mode/Drive2		
Shutter/Steady Shot	Balanced Emphasis	
Shutter/Steady Shot	AF-S	
Setup 3		
Exposure1		
Network 2		
Playback 1		
Playback 3		

Movie 1	Uncompressed	
Movie 1		Record Setting
Movie 1		Frame Rate
Shoot Mode/Drive1		
Setup 6	[set as desired]	
Playback 3		
Network 1		
Network 1	Send to Smartphone	
Network 1	<a href="#">Sending Target (proxy movies)</a>	
Setup 5	[set as desired]	
AF2	Face Priority in AF	
AF2	Face Dtct Frame Dsp	
Setup 7		[set as desired]
Playback 3		
Shutter/Steady Shot	Refer to TAB Reg Cust Shoot Set	
Playback 1		
Exposure2		
Shutter/Steady Shot	Balanced Emphasis	
Shutter/Steady Shot	Wide	SteadyShotAdjust
Shutter/Steady Shot		SteadyS.FocalLen
Playback 3		
AF1		
Setup 3		TC/UB Disp Setting
Setup 3		TC Preset
Setup 3		UB Preset
Setup 3		TC Format
Setup 3		TC Run
Setup 3		TC Make
Setup 3		UB Time Rec
Setup 2	On	
Setup 3		Operation in V Orientation
Setup 3		Touch Position Mode
Setup 3		Operation Area
Setup 3		
Setup 4		
Setup 4		
Setup 4		
Setup 7		[set as desired]
Movie 3	[set as desired]	
Network 1		
Setup 1	Auto	
Setup 1	[set as desired]	
Color/WB/Img Processing		

Network 2		WiFi Settings
Network 2		WiFi Settings
Network 2		WiFi Settings
Network 2		WiFi Settings
Movie 3	--	
FLASH		
Display/Auto Review 1	On	Display
Display/Auto Review 1		100 Level
Zoom	Off	
Zoom	Auto	
Setup 4		